

TAHOE/YUKON/SUBURBAN/YUKON XL WITH POWER DEPLOY RUNNING BOARDS

FRONT MUD GUARD INSTALLATION INSTRUCTIONS

Please read instructions thoroughly before installation.

Tools Required

- T-20 Torx

Package Contents

- Front Mud Guard
- Spring Clips X 2
- Instruction Sheet

Determine which mudguard you have by locating the part number molded in the mounting flange (5822 DS and 5822 PS).

1. Clean and degrease the mud guard location area on the fender before installation.
2. Remove existing fasteners from locations A, B and C.
3. Attach mud guard to front fender with factory fasteners at locations A, B and C. Check fit and make sure mud guard is parallel to ground before tightening. Install clip, one per side, as shown below.

