



X-ACT CONTOUR


FLOOR LINERS

CARE AND USE INSTRUCTIONS – PN:52671

Thank you for selecting an X-act Contour™ 2nd Seat Floor Liner from Husky Liners Inc. Your new floor liners are custom molded to fit your specific vehicle's floor boards. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge and soap and water. Windex®, 409® and ArmorAll® type cleaners work as well.

FRONT OF VEHICLE



TO EASE INSTALLATION OF YOUR SECOND SEAT LINERS, FIRST MOVE THE FRONT ROW SEATS TO THEIR MOST FORWARD POSITIONS. ONCE YOUR LINERS ARE INSTALLED, REPOSITION THE FRONT ROW SEATS AS DESIRED.