



WEATHERBEATER™ FLOOR LINERS

PT #1309

CARE AND USE INSTRUCTIONS

Thank you for selecting WeatherBeater® Floor Liners from Husky Liners. Your new front floor liners are custom molded to fit your Toyota Land Cruiser/Lexus LX570. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR YOUR TOYOTA LAND CRUISER / LEXUS LX 570 FRONT FLOOR LINER SET



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR FRONT LINERS, MOVE BOTH FRONT SEATS TO THEIR MOST REARWARD POSITION. POSITION THE LINERS AS SHOWN IN IMAGE ABOVE. TAKE CARE TO ATTACH THE LINERS TO THE FACTORY TWIST-LOCK RETAINING POSTS. WITH LINERS INSTALLED, REPOSITION THE FRONT SEATS AS DESIRED.