



X-ACT CONTOUR® FLOOR LINERS

PT #53261

CARE AND USE INSTRUCTIONS

Thank you for selecting an X-act Contour® Floor Liner from Husky Liners. Your new 3rd seat liner is custom molded to fit your vehicle. The liner is made to take the place of your factory floor mat(s). **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR X-ACT CONTOUR THIRD SEAT FLOOR LINER



TO INSTALL YOUR LINER, FIRST FLIP/FOLD YOUR 2ND ROW SEATS FORWARD TO ALLOW COMPLETE ACCESS TO THE 3RD ROW FLOOR PANS. WITH THIS DONE, INSTALL YOUR LINER POSITIONING IT AS SHOWN ABOVE. THE 2ND ROW SEATS CAN THEN BE FOLDED BACK DOWN INTO THEIR NORMAL USE POSITION.



X-ACT CONTOUR® FLOOR LINERS

PT #53261

NOTE THAT THERE ARE FOUR TRIMMED AREAS IN YOUR LINER THAT ALLOW THE 2ND ROW SEATS TO SECURE INTO PLACE. IF YOU EXPERIENCE ANY ISSUES WITH THE SEATS NOT SECURING PROPERLY, DO NOT USE THIS LINER. PLEASE CALL HUSKY LINERS AT 800-344-8759 FOR ASSISTANCE WITH INSTALLATION.

