

THANK YOU FOR SELECTING A HUSKY FLOOR LINER FROM WINFIELD CONSUMER PRODUCTS

CARE AND USE INSTRUCTIONS

Your new floor liner is custom molded to fit your particular vehicle. The liner is made to take the place of your factory floor mats. For correct fit, it is necessary to remove the factory floor mat before installing your new floor liner. *However, do not remove the factory-installed carpeting.*

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

INSTALLATION INSTRUCTIONS FOR YOUR TOYOTA RAV-4 SECOND SEAT FLOOR LINERS

FRONT OF VEHICLE



RAV4 LIMITED MODELS WITH 3RD ROW SEATING HAVE CLIMATE CONTROL DUCTING LOCATED ALONG THE REAR WALL OF THE 2ND ROW OF SEATS. THIS FEATURE KEEPS PART #6597 FROM FITTING CORRECTLY AS PACKAGED. HOWEVER, A TRIM AREA IS MOLDED INTO PART #6597 WHICH WILL ALLOW THIS PART TO BE TRIMMED TO ACCOMMODATE THE DUCTING. TO TRIM, REMOVE THE SECTIONS OF THE LINER SHOWN ABOVE LABELED #1 AND #2. USE THE MOLDED IN TRIM GROOVE AS YOUR TRIMMING GUIDE (SEE PHOTOS ON BACK).

TRIMMING PHOTOS OF PART #6597



PART #6597 SHOWN UNTRIMMED. NOTE THE MOLDED IN TRIM GROOVE DEFINING THE TRIM AREA.



PART #6597 SHOWN TRIMMED. NOTE TRIMMING INFORMATION IS THE SAME FOR BOTH TRIM LOCATIONS.

